

Wire Fix, WF-2

For series EnergoStrip and EnergoInfra Industry



Assembly Instruction

The wire fix, WF-2, is easy to mount. The work can be done quickly and easily without any need of making holes for screws, bolts or similar. Use work gloves for all mounting and beware of any sharp corners and edges.



Care should be taken during work, to prevent scratching the heater, the aluminium panel or the reflector.

1. Lay the heater on flat surface, on a workbench or protected on the floor.
2. Place the wire fix's protruding part, under the fixing brackets of the heater.



3. After positioning and centering the wire fix, tighten the bolt with a socket wrench.
4. Done!

ENERGOTECH